

YIILIGHTING

Programming the Remote

In order for your remote to function properly, it needs to communicate with the light itself via the same transmitter code combination. Setting the code is fairly straightforward.

1. Power your light off using the wall switch or circuit breaker.
2. Remove the batteries from the handheld remote.
3. Restore power to the light.
5. Re-install batteries in handheld remote.
6. Press and release ON button on the remote more than 5 times quickly within 30 seconds. If you see the light flashes 3 times, that means code is setted.

Group Programming

Programming multiple lights to one remote. Press and release ON button of #1 #2 #3 #4 on Group Management more than 5 times quickly within 30 seconds. If you see the light flashes 3 times, that means code is setted.

*It is only the same model products that can be programmed to one remote.

Clear Programming Setting

Power on your lighting fixture, press and release OFF button on the remote more than 5 times quickly within 30 seconds. Code setting is cleared when the light fixture flashes.

Specifications

Input Voltage: DC 3V
Standby Current: 5-10uA
Remote Control Distance: 20-30M
RF Band: 2.4GHZ-2.483GHZ

