



Model YL002524

Safety Instructions:

- Shut off the main electrical supply from the main fuse box/circuit breaker.
- Electric bulb should be centered inside the pendant shade, making sure it does not touch the outer sides.
- These instructions are provided for your safety. It is important that they are read carefully and completely before assembling fixture.

Warning:

- To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- For your safety and convenience, assembly by two people is recommended.

Assembly Instructions

SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX.

1. Mark the position of mounting bracket's holes(2 totally) on your ceiling. Drill the ceiling holes and install the provided plastic anchors into the holes you've just drilled.

2. Fix the mounting bracket with screws provided.

3. Determine the desired cord length and make electrical connections. Sort out the white wires and connect them to the NEUTRAL JUNCTION BOX WIRE; sort out the other transparent wires and connect them to the HOT JUNCTION BOX WIRE.

4. Pull canopy up over the mounting bracket, align the holes in the mounting bracket with the holes in the canopy.

5. Using the enclosed mounting screws. Tighten screws with a screwdriver.

6. Insert G4 LED bulbs (not included) into the socket . DO NOT EXCEED SPECIFIED WATTAGE. Restore power to junction box and test fixture.

Care Instructions

- Wipe clean using a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals and abrasives to clean xture as they may damage the finish.