



Programming the Remote

In order for your remote to function properly, it needs to communicate with the ceiling light itself via the same transmitter code combination. Setting the code is fairly straightforward.

1. ON: Press and release ON button on the remote more than 3 times quickly within 5 seconds. If you see the light flashes 3 times, that means code is setted. Short press to turn on the light; long press to make the light most bright.

2. OFF: Short press to turn off the light; long press to night light mode.
3. Brightness+: Short press/long press, brightness increase until the most.
4. Brightness-: Short press/long press, brightness decrease until to the night light mode.
5. Color temperature+: Short press/long press, color temperature increase all the way up to 6000K.
6. Color temperature-: Short press/long press, color temperature decrease all the way down to 3000K.
7. Night light: Short press, night light mode ON/OFF switch.
8. RGB: Short press to turn on, then short press for pause; long press to turn to red light color.
9. Auxiliary light 1: Short press, auxiliary light ON/OFF switch.
- 14/15/16/17. Group programming: Programming multiple lights to one remote. Press and release ON button of #1 #2 #3 #4 on Group Management more than 5 times quickly within 30 seconds. If you see the light flashes 3 times, that means code is setted.

*It is only the same model products that can be programmed to one remote.